


System > General > Maintenance

In the Maintenance tab, you can upgrade the system firmware. (Item 4)



Please follow the following steps to complete the FW update:

1. Download the file from our website and save it in your computer hard disk
2. Click Browse. Locate and select the file and click Open
3. Click Apply. Wait till you see the message "Firmware Upgrade OK!!" and close IE page. You can use IP finder to find the device and enter the IP Camera web page again. The default ID and password is both "admin"